


**SYMPTOM:
FUEL SELECTOR BUTTON ON
COMMUTATOR NOT WORKING**



NOTE #1
 - FROM UNDERNEATH THE INSTRUMENT PANEL, LOCATE THE ENGINE WIRE HARNESS LEAD GOING TO THE COMMUTATOR LEAD
 - LOCATE THE 2-PIN CONNECTOR
 - FIG #1 REPRESENTS A VEHICLE EQUIPPED WITH A POP SWITCH
 - FIG #2 REPRESENTS A VEHICLE NOT EQUIPPED WITH A POP SWITCH

